

SIGMA SPORT "Pulscomputer"

23105	PC 3	Allround
24105	PC 4	Allround
29105	PC 9	Allround
21503	PC 15	Allround
29100	FIT WATCH - Topline	
29102	FIT WATCH Pedometer	
28300	ONYX EASY	
28200	ONYX FIT	
28100	ONYX PRO	



Onyx Easy



Onyx Fit



Onyx Pro

Zubehör:

20306	DL 2016	Batterie	PC 3 / PC 7
270310	DL 2025	Batterie	PC 14
00342	DL 2032	Batterie	f.Brustband

20303	Brustband	analog	inkl. Elastikgurt
20310	Brustband	Digital	inkl. Elastikgurt f.Onyx
20304	Lenkerhalter	Allround	
20313	Lenkerhalter	f. Onyx	